


2x4 WOOD MEMBER SUSPENSION METHOD.  
 ATTACHED TO EXISTING SLAB WITH HARDENED  
 NAIL. SUSPEND CHANNEL WITH  
 WIRE TIE FROM REBAR CLIPS.



**NOTE:**


- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES  
 1-888-825-4716  
 techservice@ndspro.com

# TYPICAL 5" PRO SERIES INSTALLATION



## NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.


SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

# TYPICAL 5" PRO SERIES INSTALLATION

2x4 WOOD MEMBER SUSPENSION METHOD.  
 ATTACHED TO EXISTING SLAB WITH HARDENED  
 NAIL. SUSPEND CHANNEL WITH  
 WIRE TIE FROM REBAR CLIPS.



#4 REBAR HORIZONTAL PLACE TOP  
 & BTM. OF CONC. POUR 3" CLR @ BTM. (TYP)

**NOTE:**


- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES  
 1-888-825-4716  
 techservice@ndspro.com

**TYPICAL 5" PRO SERIES INSTALLATION**



**NOTE:**


- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

**TYPICAL 5" PRO SERIES INSTALLATION**



**NOTE:**

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.


SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



**TYPICAL 5" PRO SERIES INSTALLATION**

CLASS "D" 8" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ PAVERS.

TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com



**NOTE:**

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

**TYPICAL 5" PRO SERIES INSTALLATION**

CLASS 'D' 8" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD.

N. T. S.



**NOTE:**


- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 8" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.

**TYPICAL 5" PRO SERIES INSTALLATION**



TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com



SECTION AT 5" PRO SERIES


NDS # 3P05 COUPLING OR 4P05  
 COUPLING TO 3" OR 4" BTM.  
 OUTLET.  
 3" OR 4" PVC PIPE BY OTHERS

# TYPICAL 5" PRO SERIES BTM. OUTLET

3" OR 4" PVC COUPLING TO BTM. OUTLET CONNECTION.

N.T.S.






NDS 5" PRO SERIES #811 CHANNEL  
END OUTLET W/ U.V. INHIBITOR

NDS # 4P05 4" COUPLING

NDS # 4P03 4" 45 ELBOW

4" PVC BY OTHERS.

**NDS 5" PRO SERIES™ CHANNEL #811 4" END OUT.**



NDS 5" PRO SERIES #811 CHANNEL  
END OUTLET W/ U.V. INHIBITOR


3" PVC BY OTHERS.

NDS # 3P03 3" 45 ELBOW

3" PVC BY OTHERS.

NDS 5" PRO SERIES™ CHANNEL #811 3" END OUT.

N.T.S.



**NOTE:**

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

**TYPICAL 5" PRO SERIES INSTALLATION**

CLASS 'A' & 'B' 4' LOAD APPLICATION FOR CONCRETE / FORM BOARD SUSPENSION METHOD

N. T. S.



## NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

# TYPICAL 5" PRO SERIES INSTALLATION

CLASS 'A' & 'B' 4" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ PAVERS.

N.T.S.



**NOTE:**


- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

**TYPICAL 5" PRO SERIES INSTALLATION**



**NOTE:**

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.


SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 4" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 2,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.

**TYPICAL 5" PRO SERIES INSTALLATION**



TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

2x4 WOOD MEMBER SUSPENSION METHOD.  
 ATTACHED TO EXISTING SLAB WITH HARDENED  
 NAIL. SUSPEND CHANNEL WITH  
 WIRE TIE FROM REBAR CLIPS.



**NOTE:**


- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES  
 1-888-825-4716  
 techservice@ndspro.com

**TYPICAL 5" PRO SERIES INSTALLATION**



**NOTE:**

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.


SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

**TYPICAL 5" PRO SERIES INSTALLATION**





## NOTE:

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.




TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

# TYPICAL 5" PRO SERIES INSTALLATION

CLASS 'C' 6" LOAD APPLICATION FOR CONCRETE / REBAR SUSPENSION METHOD W/ PAVERS.

N. T. S.



**NOTE:**

- CHANNELS TO BE INSTALLED WITH GRATE. GRATE TO BE PROTECTED FROM CONCRETE POUR.

SET TRENCH DRAIN IN CHANNEL SURROUNDED BY 6" OF CONCRETE OR THICKNESS OF THE CONCRETE SLAB WITH A MINIMUM OF 3,500 P.S.I. AVOID FULL LOAD TRAFFIC FOR 28 DAYS OR UNTIL CONCRETE HAS COMPLETELY HARDENED.



TECHNICAL SERVICES  
1-888-825-4716  
techservice@ndspro.com

**TYPICAL 5" PRO SERIES INSTALLATION**